PODS Large Decal Field Installation Instructions



Tools Needed:



- Windex Glass Cleaner
- Liquid Soap
- Spray Bottle W/Chemical Label Identifying “Soap & Water”
- Squeegee

Materials Needed:



- PODS Large Decal for Side Walls on New Generation Containers
  - 16’ Container Decal – PG6017
  - 8’ Container Decal – PG6017-8

Personal Protective Equipment:

- Steel Toed Shoes
- Safety Glasses
- Bump Cap
- Cut Resistant Gloves
- Hearing Protection



PODS Large Decal Field Installation Instructions

1. When replacing a faded Gen 5 or Gen 6 wall panel decal in the field that does not have any rips, tears, or missing pieces, you can overlap the new decal on top of the first decal.

Note: You can only overlap 1 time. If you are replacing a faded decal that already has 2 decals applied on the panel, you **must** remove both decals before installing the new decal using the “Large Decal Installation Instructions”.



PODS Large Decal Field Installation Instructions

2. Clean old decal with Windex glass cleaner.



PODS Large Decal Field Installation Instructions

3. Lay new decal face down on a clean surface and remove backing.



PODS Large Decal Field Installation Instructions

4. Mix soap and water in a spray bottle and spray the back of the decal with the soap and water mixture.

Note: Be very generous with the mixture.



PODS Large Decal Field Installation Instructions

5. Spray old decal with soap and water mixture where the decal is to be applied.

Note: Be very generous with mixture.



PODS Large Decal Field Installation Instructions

6. Using 2 people, line up the new decal over the old decal.



PODS Large Decal Field Installation Instructions

7. Spray face of decal with soap and water mixture and start to squeegee decal from center working your way out to remove all wrinkles and bubbles.





PODS Large Decal Field Installation Instructions

8. Let decal dry for 24hrs before washing or transporting container.

